



Right-On Wrap-On!

1L, 5L, 200L (35.5 fl oz US only)



European version:

Right-On 600-Z0314

US and Japanese version:

Wrap-On! 600-Z0320

English 600-Z0314 / 600-Z0320

Application liquid for self-adhesive films

The well known and quickest application liquid!

Install wrap films and PPF on large areas with ease - no stress!

Enables you to slide large patches of film with ease, but after just minutes the film will start adhering better than without Wrap-On!/Right-On

Instructions for use

- Spray onto both the substrate and the adhesive layer.
Easily position the film on the substrate.
- Wet the outside of the film and squeegee outwards.
- Now squeegee the fluid out in overlapping strokes. The more moisture is squeegeed out, the faster the film will bond.
The Wrap-On!/Right-On fluid will gradually evaporate and adhesion to the substrate will set in.



Expert Tip for an even more efficient use of Wrap-On:

Wrap-On!/Right-On is also lightly degreasing and as such it is perfect to gently clean glas, acryl, banner materials and plastics that are sensitive to more aggressive cleaning materials.

Download the Safety Datasheet (MSDS):
www.sott-products.com

Deutsch 600-Z0314 / 600-Z0320

Anwendungsflüssigkeit für selbstklebenden Folien

Die bekannteste und schnellste Montageflüssigkeit!

Gebrauchsanweisung

- Sprühen Sie die Klebeseite der Folie und eventuell auch die jeweilige Oberfläche mit Right-On ein.
- Befestigen Sie die Folie auf der Oberfläche und besprühen Sie die Oberseite der Folie leicht mit Right-On, damit Ihre Rakel leichter über die Oberfläche gleitet.
- Reiben Sie mit der Rakel die Feuchtigkeit und alle Luftblasen von der Mitte aus weg.

Datenblatt finden und herunterladen (MSDS):
www.sott-products.com

Français 600-Z0314 / 600-Z0320

L'unique fluide pour les applications

Le liquide d'application bien connue et plus rapide!

Instructions

- Vaporisez le côté adhésif et le support avec le spray "Right-On/Wrap-On!" et appliquez la partie adhésive sur le support.
- Positionnez le film en marouflant celui-ci, puis vaporisez légèrement la face se trouvant devant vous avec le spray "Right-On/Wrap-On!" afin que la raclette glisse facilement sur la surface.
- Commencez du milieu vers les bords. Les bulles d'air seront enlevées de cette manière.
- Le processus d'accélération du collage commencera en moins de 3 minutes. Peut être dilué avec l'eau pour ralentir le processus du collage.

Fiche de données de sécurité:
www.sott-products.com

